



# Single radial rows

RECOMMENDED FOR

## APPLICATION INSTRUCTIONS

- 1 Assemble the model.
- 2 Prepare the model for the painting. Spray with Mr. Finishing Surfacer 1500, add drops of Super Gloss Clear to the mixture so that the sprayed model has glossy surface (same grade of smoothness of the surface like for decal application).
- 3 Prepare mixture of water (100 ml) and dishwashing saponite (2–3 drops). Soak the dishwashing sponge in the mixture.
- 4 Cut off a section with rivets from the decal paper with scissors or sharp modeling knife. Put it on the sponge then push the sponge so that the decal is wet.
- 5 Wait until the decal could be released from the paper. Put drops of water/saponite mixture on the model surface where you want to place the decal, then place the decal on its position.
- 6 Press the applied decal to the surface with dry dishwashing sponge and remove all water. Do not move the sponge! Just apply gentle press and then draw the sponge apart from the surface vertically. Otherwise, the decal might get deformed.
- 7 After all the decals are on their positions, allow at least 24 hours for drying. Then spray 3–5 very thin layers of Mr. Finishing Surfacer 1500 over the whole model using airbrush. Do not use spray in can!
- 8 Continue with painting and final assembly of the model. Pay maximum attention to masking when using masking tape. The adhesion of the tape must be reduced to avoid damage of the Surfacer layer or even the decal!

- 1 Sestavte model.
- 2 Připravte model na barvení. Nastříkejte jej směsí Mr. Finishing Surfacer 1500 s několika přidávanými kapkami lesklého laku, aby byl výsledný povrch hladký a lesklý. Připravte model tak, jako byste chtěli aplikovat obtisky.
- 3 Připravte si roztok jarové vody (100 ml vody a pár kapek jaru). Do roztoku namočte houbičku na nádobí.
- 4 Pomocí skalpelu nebo nůžek oddělte segment s nýty. Celý segment následně položte na mokrou houbičku a mírně zmáčkněte, aby se namočil.
- 5 Jakmile je možno obtiskem na podkladovém papíru volně hýbat, navlhčete model roztokem jarové vody na místě, kam budete obtisk umisťovat. Poté jej stáhněte z podkladového papíru na příslušné místo.
- 6 Obtisk opatrně přimáčkněte pomocí suché houbičky na nádobí na své místo a odsajte všechnu vodu. Houbičkou nesmíte po obtisku hýbat, pouze ji přikládějte vertikálně a přitlačte. Jinak hrozí deformace obtisku.
- 7 Jakmile nanesete všechny obtisky na místo, nechte je alespoň 24 hodin zaschnout. Poté celý model přestříkejte 3–5 tenkými vrstvami Mr. Finishing Surfacer 1500. Použijte stříkací pistoli, nikoli Surfacer ve spreji!
- 8 Dokončete stavbu a barvení modelu. Dbejte zvýšené opatrnosti při maskování povrchu. Použijte maskovací pásku se sníženou lepivostí, abyste nepoškodili vrstvu Surfaceru nebo dokonce nestrhli nanesené nýty!

You can find detailed instructions with step-by-step application in August 2023 issue of Eduard Info online magazine / Detailní popis postupu nanášení této sady bude součástí článku v srpnovém čísle magazínu Eduard Info 2023.



Made in Czech Republic

**eduard**

Eduard - Model Accessories,  
435 21 Obrnice 170, Czech Republic

WWW.EDUARD.COM

ER32005 Single radial rows 1/32

14,95

